

# Colour Paste Black



## Safety and health

When using WEICON Colour Paste, pay attention to the physical, toxicological and ecological data and instructions contained in our Material Safety Data Sheets.

## Available sizes:

10519250 Colour Paste Black 250 g

## Accessories:

10953001 Processing Spatula, short  
10953003 Processing Spatula, long

## special colour paste on the basis of finely dispersed pigments

Special colour paste on the basis of most finely dispersed colour pigments for the colouring of WEICON Urethane and WEICON Casting Resin MS 1000.

## Technical Data

Density of the mixture	1,00 g/cm <sup>3</sup>
IMPA-Code	81 29 84

\*The maximum dosage refers to the total weight of the mixture (resin and hardener).

## Processing

Before Colour Paste is added, it must be stirred carefully. Then, it can be added into the resin component of the Urethane or the Casting Resin MS 1000 in the maximum dosage as indicated above. In order to obtain a homogeneous mass, resin and colour paste should be mixed with a spatula for at least four minutes, taking care that no bubbles are formed. After this, the hardener component can be added. All compounds must then be mixed again homogeneously.

## Storage

Store WEICON Colour Paste in a dry place at room temperature (+20°C). At temperatures of +18 to 25°C, unopened packing units can be stored for min. 12 months from delivery date.

## Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON GmbH & Co. KG  
(Headquarters)  
Germany  
phone +49 (0) 251 9322 0  
info@weicon.de

WEICON Middle East L.L.C.  
United Arab Emirates  
phone +971 4 880 25 05  
info@weicon.ae

WEICON Inc.  
Canada  
phone +1 877 620 8889  
info@weicon.ca  
www.weicon.ca

WEICON Kimya Sanayi Tic. Ltd. Şti.  
Turkey  
phone +90 (0) 212 465 33 65  
info@weicon.com.tr  
www.weicon.com.tr

WEICON Romania SRL  
Romania  
phone +40 (0) 3 65 730 763  
office@weicon.com

WEICON SA (Pty) Ltd  
South Africa  
phone +27 (0) 21 709 0088  
info@weicon.co.za

WEICON South East Asia Pte Ltd  
Singapore  
phone (+65) 6710 7671  
info@weicon.com.sg

WEICON Czech Republic s.r.o.  
Czech Republic  
phone +42 (0) 417 533 013  
info@weiconcz.cz

WEICON Ibérica S.L.  
Spain  
phone +34 (0) 914 7997 34  
info@weicon.es