

Workshop Cleaner



free of solvents and phosphate bio-degradable

Workshop Cleaner cleans and degreases all metals, plastics, types of rubber, glass, ceramics and wood. It removes grease, oil, resin, rust, wax, nicotine, insect dirt, bitumen and tar specks.

Workshop Cleaner is free of solvent, emulsifier and phosphate compatible with oil separators (ÖNORM B 5105) and, in accordance with EC-guidelines, bio-degradable. It is highly concentrated and can be diluted to the proportion 1:40 (max.).

Workshop Cleaner contains selected foamless tensides and, in addition to manual cleaning, can be used in highpressure cleaners, part washing machines and spray apparatuses (e.g. Pump Dispenser WPS 1500). Special ingredients provide temporary corrosion protection.

Technical Data

Odour	almost odourless
Shelf life min.	12 months
Features	solvent-free, biodegradable
Colour	blue
Temperature resistance	+5 to +90 °C
Suitable for use with	WPS 1500
ISSA-Code	53.402.36/37/38
IMPA-Code	55 15 77/78/79

Processing

Apply Workshop Cleaner generously to the parts that need to be cleaned, allow it to soak in and wipe it off with a clean cloth. Repeat this action in the event of stubborn stains. The cleaning process can be shortened by warming up the product (max. +90°C). Particularly coarse dirt can be removed more simply in this way. Do not apply it undiluted to aluminium or zinc coatings (alkaline, concentrated pH value approx. 12). Protect against frost.

Storage

Keep in closed original container. Protect from direct solar radiation. Storage temperature may not exceed +50°C. Store container at cool and aired place. Store in a dry place.

Safety and health

When using WEICON products, the physical, safety technical, toxicological and ecological data and regulations in our EC safety data sheets (www.weicon.com) must be observed.

Available sizes:

15205005	Workshop Cleaner 5 L
15205010	Workshop Cleaner 10 L
15205030	Workshop Cleaner 30 L
15205500	Workshop Cleaner 500 ml

Accessories:

11850200	Hand Protective Foam, 200 ml
15830001	Adjusting Valve for cans, 5/10 L
15841500	Pump-Dispenser WPS 1500,
15841501	Extension for WPS 1500,
15842001	Pump Dispenser, Standard
15843001	Pump Dispenser Special,

Note

The specifications and recommendations given in this technical data sheet must not be seen as guaranteed product characteristics. They are based on our laboratory tests and on practical experience. Since individual application conditions are beyond our knowledge, control and responsibility, this information is provided without any obligation. We do guarantee the continuously high quality of our products. However, own adequate laboratory and practical tests to find out if the product in question meets the requested properties are recommended. A claim cannot be derived from them. The user bears the only responsibility for non-appropriate or other than specified applications.

WEICON GmbH & Co. KG
(Headquarters)
Germany
phone +49 (0) 251 9322 0
info@weicon.de

WEICON Middle East L.L.C.
United Arab Emirates
phone +971 4 880 25 05
info@weicon.ae

WEICON Inc.
Canada
phone +1 877 620 8889
info@weicon.ca
www.weicon.ca

WEICON Kimya Sanayi Tic. Ltd. Şti.
Turkey
phone +90 (0) 212 465 33 65
info@weicon.com.tr
www.weicon.com.tr

WEICON Romania SRL
Romania
phone +40 (0) 3 65 730 763
office@weicon.com

WEICON SA (Pty) Ltd
South Africa
phone +27 (0) 21 709 0088
info@weicon.co.za

WEICON South East Asia Pte Ltd
Singapore
phone (+65) 6710 7671
info@weicon.com.sg

WEICON Czech Republic s.r.o.
Czech Republic
phone +42 (0) 417 533 013
info@weiconcz.cz

WEICON Ibérica S.L.
Spain
phone +34 (0) 914 7997 34
info@weicon.es